
Article: BN AC8ZA18

Date: 23/01/2026



Illuminated selector switch 3 positions

Non-illuminated button spring-return

Non-illuminated button spring-return

Illuminated selector switch 2 positions


Illuminated button spring-return


Non-illuminated button spring-return

Illuminated button spring-return

Emergency push button

	Contacts	Diagram
Device 1	2NO	A1 — A4 A1 — A10 A2 — LED — A3
Device 2	1NO	A1 — A5 A6 — LED — A3
Device 3	1NO	A1 — A7 A8 — LED — A3
Device 4	1NO	A1 — A9 A12 — LED — A3
Device 5	1NO	B1 — B4 B2 — LED — B3
Device 6	1NC	B1 — B5 B6 — LED — B3
Device 7	1NO	B1 — B7 B12 — LED — B3
Device 8	2NC	A FD B8 — B9 B10 — B11





Connector	
	Double M12 with 12 pole at the bottom

